User Manual

Revision B

Product:Part number:Date:Brake Lining Kit9000692022-08-18

Brake Lining adjustment

Your turntable is at delivery adjusted to work perfectly. But in time the Brake Pad is grinded down when used. The brake effect will then gradually reduce.

Therefor you need to adjust the Brake manually to get a good braking effect over time.

To adjust the Brake Lining follow steps below and see describing images for each step.

- 1. Make sure that the motor is inactivated.
- 2. Loosen the nut on the bolt.
- 3. With a screwdriver, turn the bolt clockwise until the Brake Lining is locking the Turntable. Then turn it counterclockwise just enough until you can rotate the seat without braking.
- 4. Tighten the nut against the Locking Arm again.

The Brake Lining should be adjusted once a year for maintenance reasons or more often if needed.

